



otáčky	King TRS 9504	Akrapovič	Prodrive	King 2010
5500	28	26.5	26.5	26.5
6000	32.5	29	29	29.6
6500	36	32.5	32.9	33.7
7000	41	37.5	37.7	39
7500	44	41	42.5	43.7
8000	47.5	45.5	46.2	47.6
8500	50	47.5	48.7	50
9000	52	48	50.4	52
9500	52.5	46.5	51	52.5
10000	51	44	48.5	50.7
10500	48	41	46.5	47.8
11000	45	38	42	44.7